

US Model Canadian Model AEP Model E Model UK Model

STEREO TURNTABLE SYSTEM

SPECIFICATIONS

GENERAL

Power Requirements:

220, 240 V ac ~

adjustable, 50/60 Hz (UK model)

120, 220 V ac ~

adjustable, 50/60 Hz (AEP, E model)

120 V ac, 60 Hz (US, Canadian model) 16 W

Power Consumption:

Dimensions:

Approx. 480 (w) x 165 (h) x 420 (d) mm

 $18^{15}/_{16}$ (w) x $6\frac{1}{2}$ (h) x $16\frac{9}{16}$ (d) inches

including projecting parts and controls

Weight: Approx. 13kg. 28 lb 11 oz. (net)

Approx. 14.6 kg. 32 lb 3 oz. (in shipping carton)

TURNTABLE

Platter:

32 cm (125/8 in.), aluminum-alloy diecast

Motor:

DC servo-controlled linear BSL motor

Drive System:

Direct drive, crystal lock control system

Speed:

331/3 rpm, 45 rpm

Speed Control Range:

±10% (crystal lock OFF)

Starting Characteristics:

Comes to nominal speed within a 1/4

revolution (331/3 rpm) ±0.045% (DIN)

Wow and Flutter:

0.025% (WRMS)

Signal-to-Noise Ratio:

75 dB (DIN-B)

Initial Drift:

Within 0.0003%

SAFETY RELATED COMPONENT WARNING!

COMPONENTS IDENTIFIED BY SHADING AND MARK M ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

Load Characteristics: Automatic System: 0% up to 230 g tracking force

Lead-in, return, reject, repeat

TONEARM

Type:

Statically balanced, universal

Pivot-to-Stylus Length: Overall Arm Length:

330 mm (13 inches)

Overhang:

14 mm (9/16 inches)

235 mm (91/4 inches)

Tracking Error: Tracking Force

+2°27', -1°30'

Adjustment Range:

0-2.5 g

Shell Weight:

11 g

Cartridge Weight Range:

11.0-19.5 g

(including shell)

19.0-27.5 g (with extra weight)

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ !


LES COMPOSANTS IDENTIFIÉS PAR UN TRAMÉ ET UNE MARQUE A SUR LES DIAGRAMMES SCHÉ-MATIQUES, LES VUES EXPLOSÉES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DES SUPPLÉMENTS PUBLIÉS PAR SONY.




SERVICING NOTE


- 1. Wait a few minutes after the power switch is turned on.
- 2. When replacing the lamp of automatic-return detection, make the automatic-return adjustment (page 17).
- 4. When operating the set, confirm that the transit screws are removed.

3. Platter handling.





Be sure not spoil the magnetic coating (dark brown color).



MODEL IDENTIFICATION

- Specification Label -



US, Canadian model: AC 120 V 60 Hz 16 W

UK model:


 \sim 220, 240 V 50/60 Hz 16 W

AEP, E (E1, E2) model:

 \sim 120, 220 V 50/60 Hz 16 W

— Power Cord —

E1 model: euro-plug 1-551-530-00




E2 model: parallel-blade plug 1-551-473-31




SECTION 1 OUTLINE


1. BLOCK DIAGRAM





SECTION 2 DISASSEMBLY

• Follow the disassembly procedure in the numerical order













- 1. Bring the tonearm toward center spindle side.
- 2. Remove the screw (PSW2X6). → Remove the lamp.
- 3. Make automatic return adjustment












Control Cam Removal

- 1. Perform the tonearm removal (1) on page 7.
- 2. Remove the stopper, C-type; 15mm dia.










Preparation


- 1. When installing the chassis ass'y to the center shaft, perform 1 to 3 in order.
- 2. When installing the auto-return position detector to the chass'y ass'y, perform 6 and 7 in order.
- 3. When installing the shutter ass'y to the center shaft, perform 3 and 9.
 - Note; Tighten the set screw to the specified position of the shaft secured previously.
- When replacing the center shaft with a new one, adjust the shutter position so that the auto-return position detector is set as shown in Fig. H with the tonearm brought toward the center shaft to the limit.
- 4. Make sure that the CdS of the auto-return position detector does not touch the shutter.
- 5. Make the auto-return position adjustment (See page 17).

Worm Installation (for UP/DOWN motor)










- 4 Adjust the thrust screw as described below.
- 1) Connect the motor, dc ammeter and 3V dc power supply as shown.
- 2) When rotating the motor, make sure that the worm shaft does not touch the thrust screw.
- 3) Turn the thrust screw clockwise to the position where the motor current suddenly increases.
- 4) Loosen the screw about ¼ turn from the position obtained in the step 3.



SECTION 3

Cartridge-Lead Wire Replacement 1. Cartridge-Lead Wire Connection


blue: left channel (ground)






2. Cartridge Installation

Install the cartridge into the shell with the mounting screws so that the distance between the shell end and the stylus tip is $49 \text{ mm} (1^{15}/16 \text{ inches})$.




3-1. MECHANICAL ADJUSTMENTS



Stylus Height Adjustment

ADJUSTMENTS

- 1. Bring the tonearm above the record.
- 2. Lift the cueing lever up and make sure that the clearance between the stylus tip and the record is 5-9 mm ($^3/_{16}-^3/_{8}$ inches).
- 3. If necessary, loosen the lifter plate adjustment screw and adjust the lifter height.



Stylus Drop-point Adjustment

1. Set the record size selector lever to the 30 (12") position and make sure that the stylus gets down on the specified point of the test record.

Test record: YFSC-16

Record size selector lever position	Count of drop-point
30 (12")	7 to 14
25 (10")	6 to 24
17 (7")	7 to 25

2. If necessary, insert the screwdriver into the hole and adjust the drop-point by turning the adjustment screw.

To change the drop-point inward;


Turn the adjustment screw slightly counterclockwise (A).

To change the drop-point outward;

Turn the adjustment screw slightly clockwise (B).

3. Once it is properly adjusted with a 30 cm (12") record, the drop-point will be correct for 17 cm (7") and 25 cm (10") records as well.

Note: The stylus drop-point is changed to about 12 mm (1/2") by one turn of the adjustment



MEMO

3-2. ELECTRICAL ADJUSTMENTS

Turntable Speed Adjustment

1. Set the SPEED switch (S10, 11) to "45" position.



Note: Positive-going pulse and negative-going pulse must appear alternately.


- 3. If the correct waveform does not appear, adjust RV2 (45 rpm).
- 4. Set the SPEED switch (10, 11) to "33" position.




Note: Positive-going pulse and negative-going pulse must appear alternately.

6. If the correct waveform does not appear, adjust RV3 (33 rpm) so that the stroboscope pattern appears stationary.

oscilloscope






Speed Detecting Head Output Level Adjustment


Power switch: ON

 Adjust the position of the head so that the VTVM reading is 20 -50mV ac at 33 rpm.



2. Make sure that the head does not touch the turntable and tighten the screws securely.


Note: The clearance between the magnet coated rim and the speed detecting head must be more than 0.3 mm.



Speed detecting head (MGH)

Automatic Return Adjustment

- 1. Turn the power switch on.
- 2. Bring the tonearm toward the center spindle side.
- 3. Adjust RV501 for 1.5 V dc reading on the VOM®.




4. Set the stylus position as shown below. Adjust the shutter adjustment screw for 10.5 V dc reading on the VOM ©.



- 5. Play the test record (YFSB-6, BAND 2,33 rpm).
- 6. Turn the shutter adjustment screw so that tonearm starts to return at count of 15-17.
- 7. Play the test record (YFSB-6, BAND 3,33 rpm).
- Adjust RV501 so that the tonearm starts to return when only 1 kHz playback signal is heard.
 If RV501 is turned, readjust the steps 3-7 a few times.

Shutter adjustment screw



SECTION 4 DIAGRAMS

Replacement Semiconductors For replacement, use semiconductors except in (). Q1, 3~5, 101~123 IC2~4: µ PC4557 Q147, 148: 2SC1364 Q126~146, 301, Q305, 308, 401 2SC1364 Q405, 408, 409, 502 IC5: CX065A D159~163: 1S1555(1T40) Q2, 6, 10, 12, 16, 18 2SA678) (2SA844) D1~7, 11, 12 D101~158, D301 151555 Q302, 410 Q7, 9, 13, 306, 309 2SC1475 Q501 (2SC1890 (2SC1890) D8, 9: VD1221 Q8, 14:2SD476A Q303, 407: 2SC1061 D10: EQB01-11Z(EQA01-11) Q402, 403: 2SC1061(2SC1419) D401 : EQB01-06(EQA01-06) D408: EQB01-18(EQA01-18) Q11, 17: 2SB566A Q404: 2SA671(2SA755) D402:10D6 (SIB01-06) Q15: 2SC926A(2SC1890) Q406: 2SC926A D403~407) D409, 601 10E2 (SIB01-02) Q124, 125: 2SD571 D701~708: SLP24B Q304, 307: 2SA684(2SB564) H1, 2: 5GF-MS-07F IC1: CX193

Mounting diagram

Note:

• 0—: parts extracted from the component side.

B+ pattern.

• : B- pattern,

- Voltages are dc with respect to ground unless otherwise noted.
- Readings are taken with a VOM (20 $k\Omega/V$).

(DOWN): When tonearm is going down.

(UP): When tonearm is going up.

(UP/DOWN): When UP/DOWN button is pushed.

(REPEAT): When REPEAT button is pushed.

(PLAY): When playing at 33 rpm.


(AUTO STOP/START): When AUTO STOP/START

button is pushed.


No mark: POWER Switch . . . ON, in STOP mode.

END: When tonearm reaches at auto-return position.


▲: Nonflammable resistor.




4-1. MOUNTING DIAGRAM — Conductor Side —





See page 19 for replacement semiconductors and page 20 for notes.






See page 19 for replacement semiconductors and page 20 for notes.







Note: The components identified by shading and mark nare critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un tramé et une marque A sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro

Note:

1

2

3

- All capacitors are in μF unless otherwise noted, pF: $\mu \mu F$ 50WV or less are not indicated except for electrolytics.
- All resistors are in ohms, ¼W unless otherwise noted.
- $k\Omega$: 1000 Ω ; $M\Omega$: 1000 $k\Omega$
- monflammable resistor.
- : panel designation.
- Voltages are dc with respect to ground unless otherwise noted.
- Readings are taken with a VOM (20 kΩ/V).

(DOWN): When tonearm is going down.

(UP): When tonearm is going up.

(UP/DOWN): When UP/DOWN button is pushed. (REPEAT): When REPEAT button is pushed.


(PLAY): When playing at 33 rpm.


(AUTO STOP/START): When AUTO STOP/START button is pushed.


No mark: POWER Switch . . . ON, in STOP mode. END: When tonearm reaches at auto-return position.

- Voltage variations may be noted due to normal production tolerances.
- Waveforms are sketched at 33 rpm.
- adjustment for repair.
- : B+ bus.
- - : B- bus.
- Switch

Ref. No.	Switch	Position
S1	CONTROL CAM	OFF
S2	CONTROL CAM	ON
S3	CONTROL CAM	ON
S5	START	OFF
S6	STOP	OFF
S7	REPEAT	OFF
S8	UP/DOWN	OFF
S9	START/STOP	OFF
S10	SPEED 33	OFF
S11	SPEED 45	OFF
S12	POWER	OFF
S13	MUTING	OFF
S14	MUTING	OFF
S15	VOLTAGE SELECTOR	220V







Note: The components identified by shading and mark A are critical for safety. Replace only with

part number specified.

marque Asont critiques pour la sécurité. Ne les

remplacer que par une piece portant le numero

- 31 -

Note: The components identified by shading and mark

<u>↑</u> are critical for safety. Replace only with part number specified.

Company of the second s

0 0 (SZO) - 0


Note: Les composants identifiés par un tramé et une marque A sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.


В C D (2) TA, B3 x 10 (black) • Circled letters ((A) to (Z)) are applicable to European models only. TA, B3 x 10 (black) X-4858-428-0 © Cover Ass'y, top Items with no part number and/or no description are not stocked because they 0 are seldom required for routine service. All screws are Phillips (cross recess) type unless otherwise noted. (-) = slotted head Motor Cover **₽** P3 x 3 A-4608-059-A (P) X-4858-406-0 (E) Arm Rest Ass'v B3 x 12 4-808-459-21 A 4-858-451-00 B SW3 Screw, transit Screw, rest fixed 1-543-123-00 (K) 4-827-486-00 (A) 4-858-454-00 B Table, arm rest See the exploded View (4). 0 4-858-419-00 B TA, B3 x 8 Knob, selector Base, power switch 4-858-436-00 (B) \$12 <u>A</u> 1-552-531-00 (AEP, UK, E model) © Ring, selector 1-552-530-00 (US, Canadian model) © 4-858-755-00 (A) TA, B3 x 8 TA, B3 x 8 RV1 1-226-300-00 Resistor, variable (E) PSW3X14 TA, B3 x 8 10kΩ-B; PITCH X-3534-139-0 (B) Knob Ass'y, POWER Printed Circuit Board, pitch control NL /\(\bar{\Lambda}\)
1-519-152-00 (B)
Lamp, neon (10 mA) _ 4-858-437-00 © Printed Circuit Board, X-4858-433-0 () function B TA, B3 x 8 Printed Circuit Board, S10, 11
1-552-174-00 B
Switch, pushbotton; START/STOP,
UP/DOWN, REPEAT, AUTOSTART/STOP, neon lamp 4-858-420-00 B Case, storoboscope Knob, START Printed Circuit Board, TA, B3 > 4-858-122-00 (B) Printed Circuit Board, TA, B3 x 8 S5~9
1-552-174-00 B
Switch, pushbutton; STÀRT/STOP,
UP/DOWN, REPEAT, AUTO START/STOP
SPEED TA, B3 x 8 5

Note: The components identified by shading and mark

A are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un tramé et une marque A sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.





Ref. No.


Part No.

ullet Circled letters ($oldsymbol{\mathbb{A}}$ to $oldsymbol{\mathbb{Z}}$) are applicable to European models only.

	Ref. No.	Part No.		Desc	ription	
						_
			IC.			
	IC1	8-751-930-00	_		03	
			~			
	103	8-739-000-03	Œ	/ CX-0	OJA	
	D1 7		_			
-			$\overline{}$			
	•		$\tilde{}$			
⇒	D10	8-719-930-11	(B)	EQB()1-11Z	
⇒	D11, 12	8-719-815-55	$^{\circ}$	1S15.	55	
=>	D101 127	0 710 015 55	(B)	1015		
			_			
			_			
	D129-163	8-719-815-55	(B)	1815	55	
	D301	8-719-815-55	(P)	1015	5.5	
⇒			_			
			_			
			=			
			_			
					1-18	
⇒	D409	8-719-200-02	(B)	10E2		
- 1			_			
⇒	D601	8-719-200-02	(B)	10E2		
	D701_708	8-719-900-2 <i>4</i>	(C)	CI DO	4 B	
	D701-700	0-717-700-24	0	SLI 2.	+10	
		u.	LDavi			
	ш1 э		_		#C 07T	7
	п1, 2	6-719-905-07	0	3GF-N	VI S-U/I	•
	_ ^		SFOR			
			_		at 15 %	
ly. '	T /	1-446-223-00	0	Power	(AEP	, UK, E model)
	All capac				unloc	a othorwise
			_			
			\simeq		2537	mylar
			\sim			elect
			_			elect
•	U 4	1-121-961-00	(A)	4.7	25 V	elect
	~-		_			
			_		100V	polyethylene
		1-161-051-00	_			
(C8	1-108-246-00	A	0.047		mylar
(C9	1-108-239-00	A	0.01		mylar
(210, 11, 13	1-121-391-00	A	1	50V	elect
					SEE SEE SEE SEE SEE	
		All capac noted. 5s electroly C1 C2 C3 C4 C6 C7 C8 C9	IC2-4	IC1 8-751-930-00	IC2−4 IC5 8-759-145-57 © μPC4 IC5 8-759-600-65 © CX-0 Diodes Diodes	IC1 8-751-930-00

marque A sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

SECTION 6 ELECTRICAL PARTS LIST



			Description
		SEMIC	ONDUCTORS
		Tr	ansistors
	Q1	8-792-663-47	B 2SC1364
\Rightarrow	Q2	8-729-612-77	B 2SA1027R
	Q3-5	8-729-663-47	B 2SC1364
\Rightarrow	Q6	8-729-612-77	B 2SA1027R
\Rightarrow	Q7	8-760-413-10	B 2SC1475
	Q8	8-727-307-62	D 2SD476A
\Rightarrow	Q9	8-760-413-10	B 2SC1475
⇒	Q10	8-729-612-77	B 2SA1027R
	Q11	8-729-306-62	E 2SB566A
⇒	Q12	8-729-612-77	B 2SA1027R
\Rightarrow	Q13	8-760-413-10	B 2SC1475
	Q14	8-729-307-62	B 2SD476A
⇒		8-720-950-03	© 2SC926A
		8-729-612-77	B 2SA1027R
	Q17	8-729-306-62	E 2SB566A
⇒	Q18	8-729-612-77	B 2SA1027R
	O101-123	8-729-663-47	B 2SC1364
		8-729-157-11	B 2SD571
	Q126-148	8-729-663-47	B 2SC1364
	0201	0.700 ((0.47	O
	Q301	8-729-663-47	B 2SC1364
	Q302	8-729-612-77	B 2SA1027R
	Q303	8-727-316-12	D 2SC1061
⇒	Q304	8-727-468-43	© 2SA684
	Q305	8-727-663-47	B 2SC1364
	Q306	8-760-413-10	B 2SC1475
\Rightarrow	Q307	8-729-468-43	© 2SA684
	Q308	8-729-663-47	B 2SC1364
⇒	Q309	8-760-413-10	B 2SC1475
	Q401	8-729-663-47	B 2SC1364
⇒ :	Q402, 403	8-729-316-12	D 2SC1061
	Q404	8-729-317-12	E 2SA671
	Q405	8-729-663-47	B 2SC1364
	Q406	8-720-950-03	© 2SC926A
	Q407	8-729-316-12	D 2SC1061
	Q408, 409	8-729-663-47	B 2SC1364
	Q410	8-729-612-77	B 2SA1027R
⇒ (O501	8-760-413-10	(B) 2SC1475
			~
	Q501 Q502, 503	8-760-413-10 8-729-663-47	B 2SC14 B 2SC136

 ⇒ : Due to standardization, ments may be substituted diagrams.

Note: The components identified by shading and mark A are critical for safety. Replace only with part number specified.

Ref. No.

R20

Part No.

Description

1-214-176-00 (A) 68k 1/4W metal-oxide

Circled letters (A to Z) are applicable to European models only.

Ref. No.	Part No.		Descr	iption	
C14	1-131-213-21	B	0.47	35V	tantalum
C15	1-131-211-21	B	0.22	35V	tantalum
C16	1-108-242-00	A	0.022		mylar
C17	1-131-347-00	B	1	25 V	tantalum
C18	1-108-239-00	(A)	0.01		mylar
C19	1-108-227-00	(A)	0.001		mylar
C20	1-123-228-00	$\widecheck{\mathbf{B}}$	1	50V	elect
					(nonpolarized)
C21	1-108-227-00	(A)	0.001		mylar
C22	1-123-228-00	B	1	50V	elect
•					(nonpolarized)
C23	1-101-081-00	(A)	130p		
C24	1-102-491-00	Ā	51p		
C25	1-101-081-00	A	130p		
C26, 27	1-161-323-00	A	0.001		
C28	1-121-391-00	Ā	1	50V	elect
C29	1-101-004-00	A	0.01		
C30	1-161-051-00	A	0.01		(semiconductor)
C31	1-101-004-00	A	0.01		
C32, 33	1-161-051-00	A	0.01		(semiconductor)
C34	1-121-419-00	A	220	6.3V	elect
C101	1-121-391-00	A	1	50V	elect
C102-105	1-161-051-00	A	0.01		(semiconductor)
C106-108	1-121-391-00	A	1	50V	elect
C109	1-161-051-00	A	0.01		(semiconductor)
C110	1-121-726-00	A	0.47	50V	elect
C111	1-121-391-00	A	1	50V	elect
C112	1-121-395-00	A	4.7	25 V	elect
C113	1-121-479-00	A	22	16V	elect
C114-116	1-121-391-00	A	1	50V	elect
C117-120	1-161-051-00	A	0.01		(semiconductor)
		_			
C121, 122	1-121-391-00	A	1	50V	elect
C123, 124	1-161-051-00	A	0.01		(semiconductor)
C125	1-121-415-00	A	100	16V	elect
C126	1-123-054-00	A	22	16 V	elect
C127	1-123-187-00	A	10	25 V	elect
C128	1-121-391-00	A	1	50V	elect
C129, 130	1-161-051-00	(A)	0.01		(semiconductor)
C131	1-121-391-00	(A)	1	50V	elect
C132	1-121-402-00	(A)	33	10V	elect
C133-135	1-121-391-00	(A)	1	50V	elect
C136-139	1-161-051-00	(A)	0.01		(semiconductor)
C140, 141	1-121-391-00	(A)	1	50 V	elect
C142, 143	1-161-330-00	(A)	0.01		

Ref. No.	Part No.		Descr	iption	
C144, 145	1-121-391-00	(A)	1	50V	elect
C146, 147			0.01	••.	(semiconductor)
C148	1-121-391-00	(A)	1	50V	
C150	1-123-187-00	(A)	10	25V	
0,00	112010, 00		10	20 1	
C301	1-123-187-00	A	10	25 V	elect
C302	1-108-244-00	A	0.033		mylar
C303	1-131-209-21	$^{\odot}$	0.1	35V	tantalum
C304	1-123-187-00	A	10	25V	elect
C305	1-121-961-00	A	4.7	25V	elect
C306	1-121-415-00	A	100	16V	elect
C307, 308	1-123-187-00	A	10	25V	elect
C309	1-121-421-00	$^{\circ}$	220	16 V	elect
C401	1 122 107 00		10	2577	-14
C401	1-123-187-00	\simeq	10		elect
C402	1-121-410-00	\simeq	47	25V	
C403, 404		_	220		elect
C405, 406		_		50V	
C407	1-121-726-00		0.47		
C408	1-123-027-00	_	2.2		elect
C409	1-123-187-00	=	10	25V	elect
C410	1-121-357-00	_	100		elect
C411-414	1-108-377-00	(A)	0.01	100V	mylar
C601	 ↑1-108-750-00	(C)	0.033	125V	mylar
		_	(US m	the trace of the	
C601	▲1-130-098-00			the state of the state of	polyethylene
		7 ; 4		dian m	to the man the configuration
C601, 602	↑ 1-115-148-00				paper
			. 22	UK me	
			```		
C601, 602	<b>№</b> 1-108-779-00	B	0.01	300V	mylar
			(E mo	del)	
			20		
A 11 manistr	RES ors are in ohms. C	ISTO		00=1	- registers
are omitt	ed. Refer to the $k\Omega$ : $1000\Omega$ , $M\Omega$	list on	page :		
	le and adjustable			ve char	racteristic
	unless otherwise				
R2	1-214-156-00	(A)	10k	1/4W	metal-oxide
R3	1-214-140-00	$(\widetilde{\mathbf{A}})$	2.2k	⅓W	metal-oxide
R4-6	1-214-156-00	$\widecheck{\mathbf{A}}$	10k	1/4W	metal-oxide
				4.4===	

1120	1214-170-00	A ook /4W metar-oxide
R29	<u>↑</u> 1-206-652-00	(A) 330 2W metal-oxide
R187	1-213-126-00	(A) 39 ½W carbon
R411	<u></u> 1-206-686-00	(A) 8.2k 2W metal-oxide
		(non-flammable)
R507	<b>1-206-640-00</b>	(A) 100 2W metal-oxide
		(non-flammable)
RV1	1-226-300-00	E 10kΩ variable; PITCH
RV2, 3	1-224-492-00	B 100kΩ adjustable; 33/45 rpm
RV4-7	1-224-633-00	B 4.7kΩ adjustable;
	1 22 . 000 00	Gain/off set
RV501	1-224-633-00	B 4.7kΩ adjustable; auto
1001	1 22 + 033-00	return
		ictum
	SW.	ITCHES
S1	1-552-268-00	B Slide; control cam
S2	1-516-657-21	© Miniature; control cam
S3	1-552-268-00	(B) Slide; control cam
S5-11	1-552-174-00	ŏ
33-11	1-332-174-00	(B) Pushbutton; START/STOP,
		UP/DOWN, REPEAT, AUTO
S12	A 1 552 521 00	START/STOP, SPEED
312	<b>▲</b> 1-552-531-00	© Switch, pushbutton; POWER
S12	<b>1-552-530-00</b>	(AEP, UK, E model)
312	<u>//</u> 1-552-550-00	© Switch, pushbutton; POWER
S13, 14	1-552-532-00	(US, Canadian model)
S15, 14	A CONTRACTOR OF THE CONTRACTOR	B Pushbutton; MUTING
313	1-552-535-00	C) Selector, voltage
		(AEP, UK, E model)
	MICCE	LLANEOUS
M1		P Motor Ass'y (A)
M2	8-834-018-61	
MGH	1-543-123-00	Motor, DNF-1800A; UP/DOWN
NL NL	A CANADA AND A SECOND	(K) Head, speed detecting
PC	1-519-152-00	B Lamp, neon (10 mA)
PL	1-800-652-00	© Photo Conductive Cell, CdS
	1-518-234-00	(B) Lamp, 6V, 100 mA
PM	1-454-077-00	(D) Solenoid
X	1-527-380-21	① Crystal, OSC
A	1-533-051-XX	
1. M. 11.	1-533-051-XX <b>1</b> -534-777-00	A Holder, cylindrical lamp
	ZEL 1-334-777-00	E Cord, power (UK model)

 $\bullet$  Circled letters ( A to Z ) are applicable to European models only.

Description

<u></u> 1-534-817-99	E	Cord, power (AEP model)
<b>1-534-986-99</b>	<b>D</b>	Cord, power (US, Canadian model)
<u></u> 1-551-473-31	©	Cord, power (E2 model, parallel-blade plug)
<u></u>		Cord, power (E1 mode,
Property of the second		euro-plug)
1-551-546-00	$\oplus$	Cord, phono
1-561-201-00	©	Connector, neck cylinder

ACCESSORIES & PACKING MATERIALS

Ref. No.

Part No.

Part No.	Description
X-2224-011-0	© Screw Ass'y cartridge fitting
X-4858-414-0	(I) Head Shell Ass'y
3-701-613-00	A Bag, plastic; adaptor
3-701-616-00	A Bag, plastic; counter weight, head shell
3-701-630-00	A Bag, plastic; instruction manual
3-701-634-00	A Bag, plastic; turntable
3-770-542-11	© Instruction manual (AEP, E, UK model)
3-770-542-21	Instruction manual (US model)
3-770-542-11	Instruction manual (Canadian model)
3-794-329-31	Instruction martual (California model)
4-808-461-00	C Adaptor, 45 rpm
4-848-002-00	A Cushion, arm pipe
4-858-407-00	Adjuster, drop point
4-848-483-00	© Weight (A) support
4-858-585-00	© Cushion (right)
4-858-586-00	C Cushion (left)
4-858-587-00	B Case, accessory
4-858-588-00	© Bag, protection
4-858-589-00	A Protector
4-858-590-00	© Box, accessory
4-858-593-00	A Cushion, wieght bar
4-858-773-00	F Carton

Note: The components identified by shading and A mark are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un tramé et une marque A sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

1-212-713-00 B 300k ¼W metal-oxide

Note: The components identified by shading and mark

A are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un tramé et une marque A sont critiques pour la sécurité. Ne les remplacer que par une piè ce portant le numéro spécifié.

1/4 WATT CARBON RESISTORS (A) Note: Circled letter (A) is applicable to European models only.

											European n	TOUCIA	omy.
Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.
1.0	1-246-401-00	10	1-246-425-00	100	1-246-449-00	1.0k	1-246-473-00	10k	1-246-497-00	100k	1-246-521-00	1.0M	1-246-545-00
1.1	1-246-402-00	11	1-246-426-00	110	1-246-450-00	1.1k	1-246-474-00	11k	1-246-498-00	110k	1-246-522-00	1.1M	1-210-814-00
1.2	1-246-403-00	12	1-246-427-00	120	1-246-451-00	1.2k	1-246-475-00	12k	1-246-499-00	120k	1-246-523-00	1.2M	1-210-815-00
1.3	1-246-404-00	13	1-246-428-00	130	1-246-452-00	1.3k	1-246-576-00	13k	1-246-500-00	130k	1-246-524-00	1.3M	1-210-816-00
1.5	1-246-405-00	15	1-246-429-00	150	1-246-453-00	1.5k	1-246-577-00	15k	1-246-501-00	150k	1-246-525-00	1.5M	1-210-817-00
1.6	1-246-406-00	16	1-246-430-00	160	1-246-454-00	1.6k	1-246-578-00	16k	1-246-502-00	160k	1-246-526-00	1 6M	1-210-818-00
1.6	1-246-407-00	18	1-246-431-00	180	1-246-455-00	1.8k	1-246-579-00	18k	1-246-503-00	180k	1-246-527-00		1-210-819-00
1.8		20	1-246-431-00	200	1-246-456-00	2.0k	1-246-580-00	20k	1-246-504-00	200k	1-246-528-00		1-210-820-00
2.0	1-246-408-00			220	1-246-457-00	2.0k	1-246-581-00	20k	1-246-505-00	220k	1-246-529-00		1-210-821-00
2.2	1-246-409-00	22	1-246-433-00										
2.4	1-246-410-00	24	1-246-434-00	240	1~246~458~00	2.4k	1-246-582-00	24k	1-246-506-00	240k	1-246-530-00	2.4101	1-244-754-00
2.7	1-246-411-00	27	1-246-435-00	270	1-246-459-00	2.7k	1-246-583-00	27k	1-246-507-00	270k	1-246-531-00	2.7M	1-244-755-00
3.0	1-246-412-00	30	1-246-436-00	300	1-246-460-00	3.0k	1-246-584-00	30k	1-246-508-00	300k	1-246-532-00	3.0M	1-244-756-00
3.3	1-246-413-00	33	1-246-437-00	330	1-246-461-00	3.3k	1-246-585-00	33k	1-246-509-00	330k	1-246-533-00	3.3M	1-244-757-00
3.6	1-246-414-00	36	1-246-438-00	360	1-246-462-00	3.6k	1-246-586-00	36k	1-246-510-00	360k	1-246-534-00	3.6M	1-244-758-00
3.9	1-246-415-00	39	1-246-439-00	390	1-246-463-00	3.9k	1-246-587-00	39k	1-246-511-00	390k	1-246-535-00	3.9M	1-244-759-00
4.3	1-246-416-00	43	1-246-440-00	430	1-246-464-00	4.3k	1-246-488-00	43k	1-246-512-00	430k	1-246-536-00	4.3M	1-244-760-00
4.7	1-246-417-00	47	1-246-441-00	470	1-246-465-00		1-246-489-00	47k	1-246-513-00	470k	1-246-537-00		1-244-761-00
5.1	1-246-418-00	51	1-246-442-00	510	1-246-466-00	5.1k	1-246-490-00	51k	1-246-514-00	510k	1-246-538-00		1-244-762-00
5.6	1-246-419-00	56	1-246-443-00	560	1-246-467-00	5.6k	1-246-491-00	56k	1-246-515-00	560k	1-246-539-00		
6.2	1-246-420-00	62	1-246-444-00	620	1-246-468-00	6.2k	1-246-492-00	62k	1-246-516-00	620k	1-246-540-00		
"."	1 210 120 00												
6.8	1-246-421-00	68	1-246-445-00	680	1-246-469-00	6.8k	1-246-493-00	68k	1-246-517-00	680k	1-246-541-00		
7.5	1-246-422-00	75	1-246-446-00	750	1-246-470-00	7.5k	1-246-494-00	75k	1-246-518-00	750k	1-246-542-00		
8.2	1-246-423-00	82	1-246-447-00	820	1-246-471-00	8.2k	1-246-495-00	82k	1-246-519-00	820k	1-246-543-00		
9.1	1-246-424-00	91	1-246-448-00	910	1-246-472-00	9.1k	1-246-496-00	91k	1-246-520-00	910k	1-246-544-00		
ш									l				

### HARDWARE NOMENCLATURE

Screw:	P 3 x 10 L: Length in mm D: Diameter in mm Type of head
	Indicated slotted-head only.
	Unless otherwise indicated it means

cross-recessed head (Phillips type).

Reference Designation			Remarks
		SCREWS	
Р	€∋	pan-head screw	binding-head (B) screw for replacement
PWH	€	pan-head screw with washer face	binding-head (B) screw and flat washer for replacement
PS PSP	<b>85</b> 3-	pan-head screw with spring washer	binding-head (B) screw and spring washer for replace- ment
PSW PSPW	<del>0</del> \$10	pan-head screw with spring and flat washers	binding-head (B) screw and spring and flat washers for replacement
R	€3	round-head screw	binding-head (B) screw for replacement
К	₽	flat-countersunk-head screw	
RK	€□	oval-countersunk-head screw	
В	<b>(</b>	binding-head screw	
Т	<b>(</b>	truss-head screw	binding-head (B) screw for replacement
F	₽∋	flat-fillister-head screw	
RF	€⊒9	fillister-head screw	
BV	<del>(</del> )	braizer-head screw	1

Nut, Washer, Retaining	ring:
N 3	——Diameter of usable screw or shaft
	Reference designation

Reference Designation	Shape	Description	Remarks		
SELF-TAPPING SCREWS					
TA		self-tapping screw	ex: TA, P 3 x 10		
РТР	<b>=</b>	pan-head self-tapping screw	binding-head self- tapping (TA, B) screw for replacement		
PTPWH	<b>*</b>	pan-head self-tapping screw with washer face	binding-head self tapping (TA, B) screw and flat washer for replacement		
PTTWH		pan-head thread-rolling screw with washer face	binding-head (B) screw and flat washer for replacement		
		SET SCREWS			
SC	-	set screw	,		
SC	-9E3-	hexagon-socket set screw	ex: SC 2.6 x 4, hexagon socket		
NUT					
N	-[]-@-	nut			
WASHERS					
W	0	flat washer			
sw		spring washer			
LW	0	internal-tooth lock washer	ex: LW3, internal		
LW	0	external-tooth lock washer	ex: LW3, external		
RETAINING RINGS					
E	6	retaining ring			
G	<b>@</b>	grip-type retaining ring			

**Sony Corporation** 

9-958-557-11

© 1979

79D0276-1 Printed in Japan

SONY®

サービスガイド

1978年 5 月 発売

1002

ステレオターンテーブルシステム

**PS-X70** 

¥ 79,800

#### 概略仕様

電 源 AC100V, 50/60Hz(周波数切換不要)

消費電力 12W

大きさ 幅480×高さ165×奥行420(mm)

(最大突起部を含む)

重 さ 13kg

#### ターンテーブル

ターンテーブル 32cm, アルミダイキャスト

駆動方式 ダイレクトドライブ、クリスタルロック・マグネディス

クサーボ方式

回転数 33½, 45rpm

モーター リニアBSL(ブラシアンドスロットレス)モーター

速度調整範囲 ±10%(クリスタルロックOFF)

起動特性 ½回転以内(33½rpm)

ワウ・フラッター 0.025%WRMS S/N 75dB (DIN-B)

初期ドリフト 0.0003%以内

負荷特性 0%(針圧230gまで、レコード盤最外周)

速度偏差 ±0.002%以内(クリスタルロックON)

#### トーンアーム

型 式 スタティックバランス型 ユニバーサルトーンアーム

有効畏 235mm

全 長 330mm

オーバーハング 14mm

トラッキングエラー +2°27′, -1°30′

針圧調整範囲 0~2.5g

シェルの重さ 11g

使用可能なカートリッジの重さ  $11 \sim 19.5 g$ 

(付属のシェルも含む) 19~27.5g(補助ウエイト使用)

	付	属	品
45回転アダプター		1	
補助ウエイト		1	
ヘッドシェル		1	
カートリッジ取付ねじ		一式	
針位置調整用金具		1	
その他	印刷	物一式	

#### 【外観写真】



#### ・概要は次ページ参照

#### 【海外では使用できません】

本機は、電気用品取締法(安全規格)に基づいて、日本国内用 につくられております。海外向けの変更は、製品の安全規格が 日本と異なるためできません。

#### 【修理上の注意】

製品の安全性を確保するために「電気用品取締法」に従って 修理する必要があります。

安全・性能維持のため、必ず指定の部品をご使用下さい。

#### 【概 要】

- ・高安定、高精度のクリスタルロック・マグネディスクサーボ 方式採用。
- ・リニアBSL(ブラシアンドスロットレス)モーター使用。
- ・START/STOP, UP/DOWN, REPEAT, STOP-AUTO-STARTおよびSPEEDスイッチは、発光ダイオード表示のインジケーター付フェザータッチ操作ボタン採用。
- ・オートリターン機構に純電子式のルミナスセンサー方式採用。
- ・反射型ストロボスコープ採用。
- ・無共振化を目指したSBMC (ソニーバルクモールディングコンパウンド) のキャビネットとゲル状ダンプ材封入の特殊インシュレーター採用。

4. 本機は、輸送時には輸送ねじ(赤色)で電源トランスをフ

レームに固定しますが、もし、輸送ねじで固定したまま使

用すると、電源トランスの影響で音質が悪くなる場合があ

ります。修理のときは、電源トランスがフレームから浮い

た状態になるように、輸送ねじが外れていることを確認し

- ・音質重視の高感度, 防振設計のトーンアーム使用。
- ・フルオートプレーヤー。

て下さい。

#### 【修理時の注意】

- 1. 各部の点検、調整は、電源スイッチをONし、数秒たって 回路が安定してから行なって下さい。
- 2. オートリターン位置検出用ランプPLを交換したとき,位置検出感度がずれることがあるので、17ページのオートリターン位置調整を再度行い,正常にオートリターン動作することを確認して下さい。
- 3. ターンテーブルの取扱いに注意して下さい。







### 【外観名称】





#### 【ブロックダイヤグラム】




### 【内部参考写真】










### 【ストロボ用ネオンランプ(NL1), 電源スイッチ(S1) の交換】

1, ②:ネオンランプ(交換時,極性に注意する。極性は, 23,32ページのプリント図参照。)


3, 4:電源スイッチ





3 TA B3×10を取って インシュレーターを外す。

#### 【オートリターン位置検出用ランプ(PL)の交換】

- ・トーンアームの最も内側(センター スピンドル側)に持っていく。
- ・A図のPSW3×6を取る → B図のよ うになる → ランプを交換する。
- ・交換後、オートリターン位置の調整 を行う(17ページ参照)。








#### 【コントロールカムの外し方】


トーンアームの外し方の **⑨** (8ページ 参照) までを行い、右図の C型止め輪 (15 ¢)を取ることにより外せます。




#### 【機構部の組立方法】

- 1. リミッター(A)を **リードインレバー部** に取付けるときは ※3と※4がD図の関係になること。
- 2. リードインレバー部を機構部シャーシに取付けるときは、
  - 1) ブレーキレバーを矢印方向に寄せる。
  - 2) ※2が※1の矢印側になるようにする。
- 3. コントロールカム部 を 機構部シャーシ に取付けるときは、
  - 1) ブレーキレバーを矢印方向に寄せる。

  - 4) C型止め輪で止める。







- 11 -

ージ参照)

mmのLレンジで締め付ける。

### 【UP/DOWNモーターのウォーム取付け】







#### 4 スラストねじの調整をする。

#### 方 法

- 1) 左図のように接続する。
- 2) モーターが回転するが、このときウォーム軸がスラストね じに当っていないことを確認する。
- 3) DC電流計をみながら、スラストねじを徐々に締め、電流 の増え始める所で、締めを止める。
- 4) 止めた所からスラストねじを90°戻す。




# **PS-X70**



## 

# **【ヘッドシェルの傾き調整】** ターンテーブル・底板を外した状態で行う。



## 【針位置調整】


- 1. 調整穴キャップを外す。
- 2. サイズセレクターつまみを30(12)の位置にする。
- 3. テストレコード(YFSC-16)をオートスタートさせたとき、針がレコード盤上の正しい位置へ降りるように針位置調整ねじを回す。

規格 7~14カウント

**4**. サイズセレクターつまみを25(10),17(7)にしたときの 針位置を確認する。

25(10)……6~24カウント

17(7)……7~25カウント



4. 回転速度を33回転に切換える。

規格


5. オシロスコープの波形を観測する。

#### 【速度調整】

電源スイッチ:ON

- 1. 回転速度を45回転にする。
- 2. オシロスコープの波形を観測する。

規格




0 V を中心に波形が +側と-側へ交互に

アース IC1の②ピン オシロスコープ

- 3. 規格外の場合はRV2を調整する。 6. 規格外の場合はRV3を調整する。

出ること。




## 【速度検出ヘッドの出力調整】


電源スイッチ: ON

速度切換スイッチ:33回転

1. ターンテーブルを回転させ、ヘッド出力端子がAC20mV~ 50mVになるように止めねじ(B3×12)を緩めてヘッドを前 後に動かし、調整する。



- 2. 調整後、ターンテーブルを手でゆっくり回して、ヘッドと ターンテーブルの着磁面が当っていないことを確認する。
- 注) ターンテーブルの着磁面とヘッド面の間は、0.3mm(名刺の 紙厚程度)以下にならないこと。正しく調整されていない と, ワウ・フラッター悪化の要因になります。






# PS-X70 PS-X70


# 【オートリターン位置調整】

電源スイッチ:ON


- 1. トーンアームを最も内側(センタースピンドル方向)にして, ブレーキドラム組立のシャッターを全開にする。
- 2. テスターの読みがDC1.5VになるようにRV501を調整する。



3. 次に、下図のように針先がセンタースピンドルから56.5mm の位置にあるとき、シャッター調整ねじを回してテスター の読みがDC10.5Vになるように調整する。




- 4. 2, 3項を調整後、テストレコードYFSB-6のBAND2を 33回転で再生し、15~17カウントの間でリターンすること を確認する。リターンしないときは、シャッター調整ねじ を再調整する。
- 5. 次に、BAND  $3\sim 6$  を33回転で再生し、スピーカーから 1 kHz の再生音が聞えたときだけリターンすることを確認する。 リターンしないときは、RV501を微調整する。
- 6. RV501を動かした場合は, 5,6項を再確認する。
- 7. 調整後、シャッター調整ねじにロックする。



【ゲイン/オフセット調整】

ターンテーブルは外して行う。

1. 下図のジャンパー線を外して, DC1.5Vを加える。





- 2. 電源スイッチをONにする。
- 3. Q8,11(H1), Q14,17(H2)の各エミッター電圧が規格値に なるようにRV4(H1), RV6(H2)を調整する。

# ……ゲイン調整

規格:5Vp-p

4. 次に、Q8,11(H1)、Q14,17(H2)の各エミッターの波形が 下図になるように(または、DC電位が 0 V になるように) RV5(H1)、RV7(H2)を調整する。……オフセット調整





半導体外形図 ( )内は、補修。

Q1, 3~5, 101~1 Q126~146, 301, Q305, 308, 401 Q405, 408, 409, Q503



Q2, 6, 10, 12, 1 Q302, 410



Q7, 9, 13, 306, Q501



Q8, 14: 2SD476. Q303, 407: 2SC Q402, 403: 2SC



Q11, 17: 2SB56 Q404: 2SA671(2



Q15: 2SC926A(; Q406: 2SC926A



Q124, 125: 2SE





Q304, 307: 2SA



IC1 : CX193







【回路図】

↑ および 即の部品は,安全性を維持するため に、重要な部品です。従って交換時は、必ず指定の 部品を使用して下さい。

#### ・スイッチ

リファレンスNo.	名	称	現在位置				
S 1			カムストップ状態				
S 2			カム回転途中				
S 3			カムプレイ状態				
S 5	AUTO	START	OFF				
S 6	AUTO	STOP	OFF				
S 7	REPEA	\T	OFF				
S 8	UP/DC	NWN	OFF .				
S 9	START	/STOP	OFF				
S10	SPEED	33	OFF				
S11	SPEED	45	OFF				
S12	POWE	R	OFF .				
S 13	MUTIN	G	OFF				

- ・ケミコンを除くコンデンサーで,耐圧50V以下のもの は、その耐圧を省略。単位はすべてµF(pはpF)
- ・抵抗で指示のないものは¾W。
- 単位はすべてΩ。
- ・半固定抵抗の特性はすべてB。
- ・記入の電圧は20kΩ/Vテスターによる参考値。

電圧の表示

(DOWN) ……UP/DOWNボタンを操作し、DOWN動 作中の電圧

…UP/DOWNボタンを操作し, UP動作 中の電圧

(UP/DOWN) …UP/DOWNボタンを押したときの電圧。 (REPEAT) ……REPEATボタンを操作したときの電圧。


(PLAY) ……演奏中の電圧(33回転)。


(AUTO STOP/START) …同ボタンを操作または AUTO STOP/START動作中


の電圧。


表示無し……POWER ON後安定したときの電圧。 ……オートリターン位置にトーンアーム がきたときの値。


·=== はB-ライン

















・記入の電圧は20kQ/Vテスターによる参考値。


(DOWN) ·······UP/DOWNボタンを操作し, DOWN動 作中の電圧


AUTO STOP/START動作中














【分解図】

9-958-557-01

・ねじ類で特

## 【主要部品表】

◆:補修用のため、回路図、プリント図と定数又は型名が

記 号	部品コード	品 名	定価	備考	記号	部品コード	品 名	定価	備考
		半 導 体			Q 408, 409	8-729-663-47	2 S C 1364	A	
Q		   (半導体は改良のため予告なく   変更することがあります。	)		410	8-727-788-00	2 S A 678	С	+
ev L	8-729-663-47		A		501	8-760-413-10	2 S C 1475	D	+
2	8-727-788-00		C	+	502,503	8-729-663-47	2 S C 1364	A	
2 3∼5	8-729-663-47		A	_	IC				
6	8-727-788-00		C	_	1	8-751-930-00	C X 193	M	İ
7	8-760-413-10		D	1	2~4	8-759-145-57	μ P C 4557	E	
3	8-729-307-62		F	•	5	<i>"</i> -600-65	C X 065 A	Н	
9	8-760-413-10		D	+	D				
10	8-727-788-00		C	T	1~7	8-719-815-55	1 S 1555	A	+
11	8-729-306-62		F	•	8,9	<b>"</b> -122-10	V D 1221	Α	
12	8-727-788-00		C	_	10	<i>"</i> −930−11	E Q B 01-11 Z	D	+
13	8-760-413-10		D	+	11,12	" -815-55	1 S 1555	A	+
14	8-729-307-62		F	_	101~158	" -815-55	1 S 1555	A	+
15	8-729-307-02		D	_	159~163	" -815-55	1 S 1555 (機番	A	+
16	8-727-788-00		C	+	301		1 S 1555	A	
17	8-729-306-62		F	-	401	<i>"</i> -931-06	E Q B 01-06	D	+
18	8-729-300-02		C	_	402	<i>"</i> −210−06	10 D 6	C	+
				+	403~407	″ -200-02	10 E 2	A	+
101~123	8-729-663-47		A	*r +0	408	<i>"</i> -931-18	E Q B 01-18	D	+
124, 125	" -157-11	28 05/1	C	新規	409	-200-02	10 E 2	A	+
$\{\frac{126-146}{301}\}$	″ -663-47	2 S C 1364	A		601	″ -200-02	10 E 2	A	+
		/ Late XTL			$701 \sim 708$	" -900-2 <b>4</b>	SLP24B	E	
147,148		2 S C 1364 (機番 203,001以降)	A		H1,2	<i>"</i> −905−07	5GF-MS-07F	F	
302	8-727-788-00		C	+					
303	" -316-12	2 S C 1061	F				電気部品		
304	" -468-43	2 S A 684	F	+	M1	A-4608-059-A	モーター(A)組立	s	
305	<i>"</i> −663−47	2 S C 1364	A		M 2		モーターDNF-1800A	M	
306	8-760-413-10	2 S C 1475	D	+	MGH		回転数検出用ヘッド	G	
307	8-729-468-43	2 S A 684	F	+	NL	and the same of the same	ネオンランプ	c	
308	<i>"</i> −663−47	2 S C 1364	A		PL		筒型ランプ6V,100mA	D	
309	8-760-413-10	2 S C 1475	D	+	PM		ソレノイドコイル	F	
<b>1</b> 01	8-729-663-47	2 S C 1364	A		RV1		可 変 10kΩ-B(PITCH)	G	
102,403	" -316-12	2 S C 1061	F	+	RV2,3		抵 抗 100kΩ-B 抵 抗 (23 45回至)	$ _{\mathbf{D}}$	
104	<i>"</i> −317−12	2 S A 671	F	+	,•		抵 抗 (33, 45回転)		
<b>1</b> 05	<i>"</i> −663−47	2 S C 1364	A		RV4~7	<i>"</i> −633−00	" 4.7kΩ-B	В	
406	8-720-950-03	2 S C 926 A	D		DV501	, , , , , , , , , , , ,	(ゲイン, オフセット)		
407	8-729-316-12	2 S C 1061	F		RV501	<i>"</i> -633-00	" 4.7kΩ-B (オートリターン)	B	

↑ および 印の部品は,安全性を維持するため に、重要な部品です。従って交換時は、必ず指定の 部品を使用して下さい。

-XX, -X:標準化部品のため, セットに付いている部品 と異なる場合があります。

部品コード

1-552-268-00 スライドスイッチ

1-516-657-21 マイクロスイッチ

1-552-268-00 スライドスイッチ

*"* -533-00

*"* -532-00

1-446-121-00 電源トランス

1-533-051-XX 筒型ランプホルダー

1-561-201-00 ネックシリンダーコネクター

コンデンサー (単位で指示のない) ものはµF, pはpF)

50 V

1-129-720-11 0.033 630V フィルム A

50V ケミコン B

16V ケミコン A

セラミック A

〃 -546-00 プラグ付コード

1-527-380-21 水晶発振子

1-551-473-31 電源コード

1-800-652-00 CdS

1-123-228-11 1

1-102-491-11 | 51p

1-123-054-11 | 22

1-125-136-11 2200

1-161-323-11 1000p

** -174-00 プッシュボタン START/STOP, UP/DOWN, REPEAT, AUTO STOP START, SPEED

記号

S1

S2

S3

**S** 12

 $\Lambda$ T

X1

20,22

24 26,27

126

**1** 405,406

<u>ƙ</u> 601

S5~11

S 13, 14

定価

С

С

С

E

C

R

F

Α

E

K

E

Α

F

備考

名

カムストップ状態

カム回転途中

カムプレイ状態

POWER

MUTING

・抵抗,	コンデンサー	-は,	特殊な	ものだ	け載せ	てありま	す。		
それら	l外のものは,	別册	の補修	用標準	抵抗及	び補修用	標準		
コンデンサー部品価格表を参照して下さい。									

_				r				T	1		<u> </u>
	記	号	部品コード	品		名	定価	備考			浄の部品及
				抵		抗				_	
	R			(単位は	すべて	Ω)				1	
	2		1-214-156-11	10k	¹∕₄W	金属酸化	A	1%			
	3		" -140-11	2.2k	"	"	A	<i>"</i>			
	4~6		<i>"</i> −156−11	10 k	"	"	A	"			
	18		1-212-712-11	300 k	"	"	В	"			
	20		1-214-176-11	68 k	"	"	A	"			
	29		1-206-652-11	330	2 W		С		$\Lambda$		<b>■</b> A
	187		1-244-839-11	39	½W	カーボン	A				4-857-601-C ダストカバークッ
	411		1-206-690-01	12 k	2 W	金属酸化	С	不燃性	$\Lambda$	_	
-	507		<i>"</i> −640−11	100	,	,,	С	η	⚠	2	4-85{ ターン:
						, ,					4-85{ ターン
										١	ターンラ
											Times
											4 (300 000 1-
-											4-836-828-00 SONYバッシ゛ <i>拳</i> F
				付	属	品					\
			X-2224-011-0	カートリッシ			F				\
			X-4858-414-0	ヘッドシェ	ル組	立	K			3	\
ı			3-770-542-01	取扱説明書	-		D				
			4-808-461-00	45回転アタ	゙プタ	-	F				
			4-858-407-00	針位置調整	用金	具	Α				注 4-858-530-00 . インシュレーターベー
			"	補助ウエイ	٢		D				<i>₩</i> TA,
			•								17.19
						,					X- 4858-403-0
											X- 4858-403-0 インシュレーター刹
										4	
											TA, B3x1( (黒)
										l	(111)
			r.								`. X·
								Þ			
			•					۵		- 1	
		_					-	) )			
										5	
		•									⚠ および 三印の
										l	に、重要な部品です
											部品を使用して下さ

# PS-X70 PS-X70

# -XX, -X:標準化部品のため、セットに付いている部品 と異なる場合があります。

+

+

+

・抵抗、コンデンサーは、特殊なものだけ載せてあります。 それ以外のものは、別册の補修用標準抵抗及び補修用標準 コンデンサー部品価格表を参照して下さい。

	記号	部品コード	品 名	定価	備考	記号	部品コード	品	名	定価	備考	
	S1	1-552-268-00	スライド カムストップ状態 スイッチ	С				抵	抗			
	S 2	1-516-657-21	マイクロ カム回転途中	D		R		(単位はすべて	Ω)			
	S3	1-552-268-00	スライド カムプレイ状態	С		2	1-214-156-11	10k ¼W	金属酸化	A	1%	
	S5~11	"	START/STOP, リアクシュボタン UP/DOWN, REPEAT, AUTO STOP START, SPEED	С		3 4~6	" -140-11 " -156-11	2.2k " 10k "	n	A A	n ·	
A	S12	<i>"</i> -533-00	" POWER	E	2,50	18	1-212-712-11	300 k "	"	В	"	
	S13,14	" -532-00	" MUTING	C		20	1-214-176-11	68 k "	"	A	"	
Æ		1-446-121-00		R	1	29	1-206-652-11	330 2 W		С		1
	X1	1-527-380-21	水晶発振子	F	200	187	1-244-839-11	39 ½w	カーボン	Α		
	ΛI		小明光版子   筒型ランプホルダー	A		411	1-206-690-01	12k 2W	金属酸化	С	不燃性	1
٨	32 08	the state of the	Net en el periodición de la companya del companya del companya de la companya de			507	<i>"</i> -640-11	100 *	"	С	"	1
Æ		1-551-473-31		E	er e autorio		A fig. 1 twee 127 15			l de la		ľ
		" -546-00		K								
			ネックシリンダーコネクター	K								
		1-800-652-00	CdS	Е								
<u>^</u>	C 20,22 24 26,27 126 405,406 601	1-123-228-11 1-102-491-11 1-161-323-11 1-123-054-11 1-125-136-11 1-129-720-11	51p セラミック 1000p " 22 16V ケミコン 2200 50V *	B A A F A			X-2224-011-0 X-4858-414-0 3-770-542-01 4-808-461-00 4-858-407-00 " -483-00	ヘッドシェル組 取扱説明書 45回転アダプタ	<u>立</u>	F K D F A D		

↑ および 印の部品は、安全性を維持するために、重要な部品です。従って交換時は、必ず指定の部品を使用して下さい。

